

SILYNX 1-Year Limited Warranty

Silvnx Communications, Inc. warrants that this product will be free from defects in design. material, and workmanship during normal use for a period of one (1) year from the date of product purchase. This warranty shall extend only to the buyer on the original receipt and may not be transferred to any other party. This warranty is valid only when and if:

(a) Written notice of the product failure is received within the warranty period: (b) The product is properly packed and returned by the buyer; and

(c) The product has not been subjected to misuse, neglect, improper use, accident, acts of war, or any unauthorized modification, repair, or alteration, as determined solely by Silvnx Communications. Inc.

This warranty excludes consumable items such as ear retainers, foam ear plugs. batteries, and similar items. During the warranty period, the exclusive obligation of Silynx Communications. Inc. shall be limited to repair or replacement of any defective part or parts, or a full refund of the price originally paid for the product, based on the sole discretion of Silvnx Communications. Inc. There are no other warranties, either express or implied, and in no event shall Silynx Communications, Inc. be liable for any losses or damages caused by floods, lightning, other acts of nature, or any Force Majeure.

Customer Service

customersupport@silynxcom.com | 866.325.1731

Silynx Communications, Inc. reserves the right to change product specifications without notice

POWER & CONTROLS

The level of hearing enhancement to be used depends on your own hearing and the ambient noise in your surroundings. The table below indicates the incremental dB gain at each Hear-Thru level.

Action (after powering unit "on")	State	dB Gain
Press button once	High	+9dB
Press button twice	Super Normal	+12dB
Press button thrice	High	+9dB
Press button fourth time	Medium	+6dB
Press button fifth time	Low	+3dB
Continue pushing button	Cycles Hear-Thru levels	N/A
Press & hold control button	Power Off	_

Note: Music / mobile phone audio can be heard when Hear-Thru is "off", but system must be powered on.

MOBILE/MUSIC CONTROLS

Mobile Phone:

- Press to answer call
- Press again to end call


Music:

- Press to pause music
- Press again to restart music
- Press twice rapidly to skip to next song
- Press rapidly three times to return to previous song

Note: Volume adjustments to music and / or cell phone are made directly on mobile device

INSERTING EARBUDS

A firm fit ensures all-day comfort, maximum hearing protection, and a quality audio experience. Here are a few tips to ensure the right fit.



(a) Roll foam ear tip between fingers before inserting. (b) Hold top of ear gently back and outward to open ear canal before inserting. (c) Place ear tip in ear, then "twist" ear bud so that cable is on top, facing forward. After inserting, gently hold ear bud in ear to allow foam to rebound to its full form to create a seal within ear canal. (d) Route wires behind ear. Use hook retainers for most secure fit. (e) Replace ear tips after 3-4 weeks of use.



Mobile phone not in use

- Route cables behind ears
- Tighten nape adjuster behind neck
- Attach control unit to back of collar or hat

DONNING THE CLARUS PRO





Mobile phone in use

- Route cables behind ears
- Tighten nape adjuster behind neck
- Attach control unit to belt in front for use of mic

SILYŇX CLARUS Pro **RUGGED NOISE**

CANCELLING HEADSET